

Kód HART	Popis	LPR	Textar
226 454	HAM.SZCZEKI VOLVO 440 88- /203X38/	5750	
226 453	HAM.SZCZEKI FIESTA 96- /203,2X38/	8200	
226 451	HAM.SZCZEKI E-CLASS 04- /180X25/ HAM.RECZNY		91058800
226 447	HAM.SZCZEKI KIA CEED /HAM.RECZNY/		91068100
226 449	HAM.SZCZEKI CORSA 84-91 /200X28/		91033000
226 456	HAM.SZCZEKI COLT VI 1.1-1.5 04- /203X38/		91068800
226 459	HAM.SZCZEKI CITROEN ZX 1.6 91- /180X32/	7830	
226 458	HAM.SZCZEKI DB SMART 99- /203X32/	7750	
226 457	HAM.SZCZEKI FIAT PUNTO 03-05 /203X38/	9090	91065300
226 446	HAM.SZCZEKI SPRINTER 06- /180X25/		91066800
226 445	HAM.SZCZEKI TOUAREG Q7 06- HAM.RECZNY		91062400
226 441	HAM.SZCZEKI TOYOTA YARIS 99- /200X32/	7860	91053500
226 443	HAM.SZCZEKI DB ML 98- /183X31/	8720	
226 444	HAM.SZCZEKI HONDA CR-V II 02- /167,4X35/		91062800
226 442	HAM.SZCZEKI SUZUKI SAMURAI 86- /220X39/	5920	
226 450	HAM.SZCZEKI XSARA 1.7D,1.8,1.9 97-	7500	
226 448	HAM.SZCZEKI PEUGEOT 405 88- /228,6X42/	3330	
226 452	HAM.SZCZEKI ESPACE -96 /228.6X42/	771	